

Thule Heavy-Duty Load Carriers.



BARS

Item number	390	391	392	393	394	395
Length (mm)	1200	1350	1500	1750	2000	2200

FEET

Type of vehicle roof



Type of foot

Product name	Rapid Fixpoint XT	Rapid Crossroad	Rapid Railing	Rapid System	Rapid Tracker	Gutter Foot	Gutter Foot	Gutter Foot
Item number	751	775	755	750	4700	9511	9521	9531
Load capacity, per pair of bars (kg)	100	100	100	75	100	100	100	100
Foot height (cm)	9.5	5.5	7.5	14	11.5	15	20	28
Lock	Included	Included	Included	One Key System 544	One Key System 544	527	527	527
Fitting kit needed	yes	no	no	yes	yes	no	no	no
Tool key 379 needed	no	no	yes	yes	no	no	no	no
TÜV approved	yes	yes	yes	yes	yes	yes	yes	yes
Fulfills City Crash norms	yes	yes						
Miscellaneous		Railing sizes 20-68 mm	Railing sizes 18-50 mm					

Short Roof Adapter SRA

For vehicles with a short roof, this adapter provides the necessary distance between the front and the rear bars. The SRA is listed as the recommended solution for those vehicles where it is needed. Item number 777.

Fit Guide: Heavy-Duty Load Carriers.

Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	2 bars	4 bars
------	-----	-----	------	------	-----	-----	------	-----------------	------------	--------------	--------	--------

CITROËN

Berlingo Top, 5-dr, MPV, with roof railing, 01-	755	391		Incl.						379		75
Berlingo, 5-dr, Van with roof railing, 97-	755	391		Incl.						379		75
Berlingo, 5-dr, Van, without roof railing, 97-	750	391	1184	544						379		50
C8, 5-dr, MPV with T-profile, 03-	751	391	3035	Incl.								100
Despatch, 3-dr, Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				200
Despatch, 4-dr, Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				200
Despatch, 5-dr, Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				200
Jumper, 4-dr, Van, 06-	751	393	3031	Incl.	751	393	3031	Incl.				100
Jumper, 2-dr, Single Cab, 06-	750	393	1439	544						379		37.5
Jumper, 4-dr, Double Cab, 06-	750	393	1439	544						379		75
Jumpy, 3-dr Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				100
Jumpy, 4-dr Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				100
Jumpy, 5-dr Van, 97-	751	391	3023	Incl.	751	391	3048	Incl.				100

FIAT

Doblo, 3-dr, Van with fixpoint, 00-	751	392	3021	Incl.								75
Doblo, 5-dr, Van with fixpoint, 00-	751	392	3021	Incl.								75
Doblo, 5-dr, Van with fixpoint, high roof 00-	No fit											
Doblo Mailibo, 5-dr Van with roof railing 00-	755	391		Incl.						379		75
Ducato, 4-dr, Van, 06-	751	393	3031	Incl.	751	393	3031	Incl.				100
Ducato, 2-dr, Single cab, 06-	750	393	1439	544						379		37.5
Ducato, 4-dr, Double cab, 06-	750	393	1439	544						379		75
Scudo, 3-dr, Van, 97-	751	391	3023	Incl.								100
Scudo, 4-dr, Van, 97-	751	391	3023	Incl.								100
Scudo, 5-dr Van, 97-	751	391	3023	Incl.								100
Strada, 2-dr, Pickup, 04-	No fit											
Strada, 2-dr, Pickup, with roof railing, extended 04-	755	390		Incl.						379		75
Strada, 2-dr, Pickup with roof railing, 04-	No fit											
Ulysse, 5-dr, MPV, 03-	751	391	3035	Incl.								100

FORD

Ranger, 4-dr, Double cab, 98-	750	392	1292	544								379
Ranger, 4-dr, Super cab, 03-	750	392	1292	544								379
Connect Tourneo, 5-dr, Van with fixpoint, 03-	751	392	3021	Incl.								75
Connect Transit, 4-dr, Van with fixpoint, 03-	751	392	3021	Incl.								75
Transit, 120/130/160/190, 75-85	9521	393		527	9521	393		527				100
Transit, 120/130/160/190, 86-99	9511	393		527	9511	393		527				100
Transit, 2-dr, Pickup, 00-	9511	394		527								100
Transit, 2-dr, Double cab, 00-	9511	394		527								100
Transit, 5-dr, Van, 00-	9521	394		527	9521	394		527				100

HYUNDAI

H-1, 4-dr, Van with roof railing, 97-	755	390		Incl.								379
Starex, 5-dr, Van with roof railing, 97-	755	390		Incl.								379



LANCIA

Phedra, 5-dr, MPV with T-profile, 03-	751	391	3035	Incl.								100
---------------------------------------	-----	-----	------	-------	--	--	--	--	--	--	--	-----

MAZDA

B-serie, 2-dr, Single cab, 98-	750	392	1292	544								379
Freestyle, 4-dr, Maxi cab, 03-	750	392	1292	544								379
Pickup B 2000, 2-dr, Pickup, 95-05	9511	392		527								75

Fit Guide: Heavy-Duty Load Carriers.



									Tool key needed	SRA needed	Max load, kg	
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock			2 bars	4 bars
MERCEDES												
Sprinter, 4-dr, Van, 95-05	9521	394		527	9521	394		527			100	200
Sprinter, 4-dr, Van with T-profile, 06-	751	393	3027	Incl.	751	393	3027	Incl.			100	200
Sprinter, 4-dr, Van with T-profile, high roof, 06-	751	393	3027	Incl.	751	393	3027	Incl.			100	200
Sprinter, 4-dr, Van with T-profile, Extra high roof, 06-	No fit											
Sprinter, 4-dr, Van with fixpoint, 06-	751	393	3032	Incl.	751	393	3032	Incl.			100	200
Sprinter, 4-dr, Van with fixpoint, High roof, 06-	751	393	3032	Incl.	751	393	3032	Incl.			100	200
Sprinter, 4-dr, Van with fixpoint, extra high roof, 06-	No fit											
Vito, 4-dr, Van with fixpoint, 04-	751	393	3029	Incl.							100	
Vito, 4-dr Van with roof railing, 97-	775	392		Incl.	775	392		Incl.			100	200
Viano, 5-dr, MPV with roof railing, 97-	775	392		Incl.	775	392		Incl.			100	200
Vaneo, 5-dr, MPV with roof railing, 02-	755	391		Incl.	755	391		Incl.	379		100	200

MITSUBISHI												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Delica, 5-dr, Van, -83	9511	392		527							100	
Delica, 5-dr, Van, high roof -83	9521	392		527							100	
L200, 2-dr, Pickup, extended, 98-	750	392	1116	544					379		75	
L200, 2-dr, Pickup, 98-	750	392	1116	544					379		75	
L200, 4-dr, Double cab, 00-	750	392	1236	544					379		75	
L200, 4-dr, Double cab, 98-99-	750	392	1116	544					379		75	
L300, 5-dr, Van, 81-02	521	392		527	521	392		527			100	200

NISSAN												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Kubistar, 5-dr, Van with fixpoint, 04-	751	392	3021	Incl.							75	
Interstar, 4-dr, Van with fixpoint, 02-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Interstar, 5-dr, Van with fixpoint, 02-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Primastar, 4-dr, Van with fixpoint, 02-	751	393	3046	Incl.	751	393	3047	Incl.			100	200
Primastar, 5-dr, Van with fixpoint, 02-	751	393	3046	Incl.	751	393	3047	Incl.			100	200

OPEL												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Combo, 3-dr, Van with fixpoint, 02-	751	392	3006	Incl.							75	
Combo, 4-dr, Van with fixpoint, 02-	751	392	3006	Incl.							75	
Combo, 5-dr, Van with fixpoint, 02-	751	392	3006	Incl.							75	
Combo tour, 4-dr, Van with fixpoint, 02-	751	392	3006	Incl.							75	
Combo tour, 5-dr, Van with fixpoint, 02-	751	392	3006	Incl.							75	
Movano, 4-dr, Van with fixpoint, 98-03, 04-06, 07-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Movano, 5-dr, Van with fixpoint, 98-03, 04-06, 07-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Vivaro, 2-dr, Single cab with fixpoint, 01-	751	393	3047	Incl.							50	
Vivaro, 4-dr, Van with fixpoint, 01-	751	393	3046	Incl.	751	393	3047	Incl.			100	200
Vivaro, 5-dr, Van with fixpoint, 01-	751	393	3046	Incl.	751	393	3047	Incl.			100	200

PEUGEOT												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
806, 5-dr, MPV with T-profile, 94-02	751	391	3035	Incl.							100	
807, 5-dr, MPV with T-profile, 03-	751	391	3035	Incl.							100	
Boxer, 4-dr, Van, 06-	751	393	3031	Incl.	751	393	3031	Incl.			100	200
Boxer, 2-dr, Single cab, 06-	750	393	1439	544					379		37,5	
Boxer, 4-dr, Double cab, 06-	750	393	1439	544					379		75	
Expert, 3-dr, Van with fixpoint, 97-	751	391	3023	Incl.	751	391	3048				100	200
Expert, 4-dr, Van with fixpoint, 97-	751	391	3023	Incl.	751	391	3048				100	200
Expert, 5-dr, Van with fixpoint, 97-	751	391	3023	Incl.	751	391	3048				100	200
Partner, 5-dr, Van, 97-	750	392	1184	544					379		100	
Partner air, 5-dr, MPV with roof railing, 01-	755	391		Incl.					379		75	

									Tool key needed	SRA needed	Max load, kg	
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock			2 bars	4 bars
RENAULT												
Kangoo, 5-dr, Van with fixpoint, 98-	751	391	3021	Incl.							75	
Master, 4-dr, Van with fixpoint 98-03, 04-06, 07-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Master, 5-dr, Van with fixpoint 98-03, 04-06, 07-	751	393	3045	Incl.	751	393	3045	Incl.			100	200
Trafic, 2-dr, Single cab with fixpoint, 01-	751	393	3047	Incl.							50	
Trafic, 4-dr, Van with fixpoint, 01-	751	393	3046	Incl.	751	393	3047	Incl.			100	200
Trafic, 5-dr, Van with fixpoint, 01-	751	393	3046	Incl.	751	393	3047	Incl.			100	200

SEAT												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Inca (Mk.I), 3-dr, Van with fixpoint, 96-03	751	391	3007	Incl.							75	
Inca (Mk.I), 3-dr, Estate with fixpoint, 96-03	751	391	3007	Incl.							75	

TOYOTA												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Super carry, 5-dr, Van, 86-98	9521	393		527							100	
Hi ace, 5-dr, Van, 83-95	9521	393		527	9521	393		527			100	200
Hi ace, 5-dr, Van, 96-06, 07-	751	392	3043	Incl.	751	393	3043	Incl.			100	200
Hi lux, 2-dr, Pickup, extended, 87-95	750	392	1118	596					379	777	75	
Hi lux, 2-dr, Pickup, extended, 98-04	750	392	1083	544					379		60	
Hi lux, 2-dr, Pickup, 98-04	750	392	1083	544					379		30	
Hi lux, 2-dr, Single cab, 05	750	392	1348	544					379		50	
Hi lux, 4-dr, Double cab, 05-	750	392	1350	544					379		50	
Hi lux, 4-dr, Double cab, 98-04	750	392	1083	544					379		60	

VOLKSWAGEN												
	Foot	Bar	Kit	Lock	Foot	Bar	Kit	Lock	Tool key needed	SRA needed	Max load, kg	
Caddy (Mk.II), 3-dr, Van with fixpoint, 98-03	751	391	3007	Incl.							75	
Caddy (Mk.II), 3-dr, Estate with fixpoint, 96-03	751	391	3007	Incl.							75	
Caddy (Mk.III), 4-dr, Van with fixpoint, 04-	751	391	3022	Incl.							75	
Caddy (Mk.III), 5-dr, Van with fixpoint, 04-	751	391	3022	Incl.							75	
Caddy (Mk.III), 4-dr, Estate with fixpoint, 04-	751	391	3022	Incl.							75	
Caddy (Mk.III), 5-dr, Estate with fixpoint, 04-	751	391	3022	Incl.							75	
Crafter, 4-dr, Van with T-profile, 06-	751	393	3027	Incl.	751	393	3027	Incl.			100	200
Crafter, 4-dr, Van with T-profile, high roof, 06-	751	393	3027	Incl.	751	393	3027	Incl.			100	200
Crafter, 4-dr, Van with T-profile, extra high roof, 06	No fit											
Crafter, 4-dr, Van with fixpoint, 06-	751	393	3032	Incl.	751	393	3032	Incl.			100	200
Crafter, 4-dr, Van with fixpoint, high roof, 06-	751	393	3032	Incl.	751	393	3032	Incl.			100	200
Crafter, 4-dr, Van with fixpoint, extra high roof, 06-	No fit											
LT, 4-dr, Van with high roof, 97-02	9531	395		527	9531	395		527			100	200
Transporter (T4), 91-96, 97-02	No fit											
Transporter (T4), high roof, 91-96, 97-02	9521	392		527	9521	392		527			100	200
Transporter (T5), 2-dr, Single cab with fixpoint, 03-	751	392	3034	Incl.							100	
Transporter (T5), 4-dr, Double cab with fixpoint, 03-	751	392	3034	Incl.							100	
Transporter (T5), 4-dr, Van with T-profile, 03-	751	392	3034	Incl.	751	392	3044	Incl.			100	200
Transporter (T5), 4-dr, Van with fixpoint, 03-	751	392	3034	Incl.	751	392	3044	Incl.			100	200
Transporter (T5), Van, high roof, 03-	No fit											
Transporter (T5), Van, extra high roof, 03-	No fit											